



Plan View

10'



## ***SETUP INSTRUCTIONS***



= 1 sq foot

## General Setup Instructions


- Read entire setup instruction manual prior to unpacking parts and pieces.
- The setup instructions are created specifically for this configuration.
- Setup instructions are laid out sequentially in steps, including exploded views with detailed explanation for assembly.

## Cleaning & Packing


- For Cleaning Metal, Plex, & Laminate Parts: Use a **MILD NON-ABRASIVE** cleanser and soft cloth/paper towel to clean all surfaces.
- Keep exhibit components away from heat and prolonged sun exposure.  
**Heat and UV exposure will warp and fade components.**
- Retain all provided Packing Materials. All provided packing materials are for ease of repacking & component protection.

## Disassembly


- For loss prevention, tighten all set screws and locks during disassembly.




Hex Tool - Essential for Assembly




Part Identification - Numbering




Spline Connection



Base Plate & Extrusion Connection




Extrusion & Lock Connection




Engaged Lock



# WARNING



DO NOT USE POWER TOOLS




LADDERS OR LIFTS  
MAY BE REQUIRED




ALL CONNECTIONS MUST  
BE TIGHTLY SECURED


## Top View of Each Level




Level 1  
(Bottom level)




Level 2




Level 3



Level 4



Level 5




Item	Qty.	Description
1	3	8" x 22" ESF-1 Oval Base Plate
2	1	47"h RSG540 Vertical Extrusion
3	1	47"h RSG540 Vertical Extrusion
4	1	47"h Z45 Vertical Extrusion
5	1	34.362"h Z45 Vertical Extrusion
6	1	47"h RSG540 Vertical Extrusion
7	1	47"h RSG540 Vertical Extrusion
8	1	47"w Z45 Horizontal Extrusion w/ Velcro
9	1	48.739" Z45 curved Extrusion w/ Velcro
10	1	47"w Z45 Horizontal Extrusion w/ Velcro
11	1	47.121" Z45 curved Extrusion w/ Velcro
--	2	45.202"h PR63 Conduit w/ Velcro
--	1	44.5"h PR63 Conduit w/ Velcro
--	1	30.5"h PR63 Conduit w/ Velcro




Steps:

Note: All Velcro faces **front** of the booth.

- 1) Attach Base Plates [1] to bottom of verticals [2,4,6] using bolts.
- 2) Assemble verticals [2-3], [4-5], [6-7] using PR53 connectors. See [PR53 Connector](#) detail.
- 3) Attach horizontals [8,9], [10,11] between vertical assemblies as shown.
- 4) Attach **PR63 conduit** to verticals & affix **Fabric Graphic** to front of frame using Velcro.



When assembled



FRONT VIEW

**\* PR63 Attachment**


Attach PR63 conduit by pinching the opening and inserting into the groove of extrusion. Velcro faces **front** of booth.

PROFILE VIEW


Steps:

- 1) Attach Wings & Headers to A10 clamps on extrusions as shown.  
See [Wing Attachment](#) detail.


**\* Wing Attachment**



- 1) Slide A10 connector into groove of extrusion.
- 2) Tighten set screw to secure A10 to extrusion.
- 3) Insert Wing into Clamp.
- 4) Tighten knob to secure wing in place.



FRONT VIEW



Completed Assembly